

Anthony Jaku, Miguel Fernandez , Esteban Perez

Mr. Thomas

AP Physics C: Mechanics


October 22, 2025

## **Momentum Lab Report**

### **Purpose:**

to determine the graphical and mathematical relationship between ratio of masses and ratio of velocities between the two carts moving apart

### **Apparatus:**



### Procedure:

1. Place Vernier Track on flat table
2. Find mass of both carts using a scale
3. Connect carts to Vernier Graphical Analysis App
4. Place both carts near the center of the track
5. Select collect on the Vernier app and press the trigger located on one of the carts  
to launch the carts
6. Reset carts to middle of track
7. Find mass of a weight and place weight on one of the carts

8. Add mass of the weight to the total mass of the cart
9. Hit trigger and collect velocity
10. Repeat steps 6-9, adding a weight each trial to the same cart and recording velocity

### Data Table:

11:41AM Thu Oct 9

Untitled

**Data Set 1**

	M1 (yellow) ... (Kg)	M2 (blue) ... (Kg)	V1 (yellow) ... (m/s)	V2 (blue) ... (m/s)	M1/M2 (Kg) ...	V1/V2 (m/s) ...	M2/M1 (Kg) ...
1	0.2772	0.2766	0.552	0.558	1.002	0.989	0.998
2	0.4016	0.2766	0.435	0.624	1.452	0.697	0.689
3	0.5258	0.2766	0.354	0.650	1.901	0.545	0.526
4	0.6505	0.2766	0.308	0.701	2.352	0.439	0.425
5	0.7748	0.2766	0.244	0.669	2.801	0.365	0.357
6	1.2975	0.2766	0.158	0.715	4.691	0.221	0.213
7	1.8215	0.2766	0.120	0.773	6.585	0.155	0.152
8	2.3267	0.2766	0.095	0.788	8.412	0.121	0.119
9	2.8335	0.2766	0.079	0.799	10.244	0.099	0.098
10							

Mode: Manual Entry

Graph  
1 Graph


Data Table


Meters

Video

Notes

### Graphs and Analysis:





$$Y=0.9954x$$

### Conclusion:

The data collected in this experiment showcases an inverse relationship between the ratio of masses and the ratio of velocities between two carts that moved apart due to a spring mechanism based interaction. Initially, the raw data was plotted as  $V1/V2$  vs  $M1/M2$ . This created a curved graph, indicating that there was a nonlinear relationship between the two ratios. In order to linearize this, we plotted  $V1/V2$  against  $M2/M1$  which yielded a straight line with a slope of approximately 0.9954 and a y intercept which proved to be negligible, making the relationship

between the two ratios proportional. Based on this now linearized graph, we are able to derive the equation that  $V_1/V_2 = M_2/M_1$ ; from here we are able to manipulate this equation into  $M_1V_1=M_2V_2$ ,  $M_1V_1-M_2V_2=0$ . This can also be simplified down into  $P_1 + P_2 = 0$ . These equations all align with the theoretical model of the conservation of momentum. The slope of almost 1 reflects this ideal momentum transfer, and the small intercept may be a result of minor experimental errors. These errors may include friction between the carts and the track, inconsistencies in the mass of the carts which should be equal, sensor calibration. In order to improve the accuracy of these trials, we could reduce said friction, calibrate the sensors more precisely, or get equal cart masses. Overall, this experiment demonstrated the expected momentum relationship and validated the theoretical model of momentum conservation through graphical analysis.